Item Number

RAM No-Drill™ Seat Bases

RAM-VB-105 & RAM-VB-105-SW1

RAM Mounting Systems

SPECIFICATIONS

Placement

Passenger side on the floor, at front of seat

Drilling Required

No - uses existing seat bolts

Seat Configuration

Bucket

Construction/Finish

Steel/Black Powdercoat

Dimensions

A = 14.75", B = 3.8", C = 1.75" Hole Center = 13.125"

Pole or Pedestal

Sold Separately

4" riser included for better positioning of pedestal in later model vehicles.

Weight: 2.1 lbs.



Complete Vehicle Mount RAM-VB-105-SW1

Vehicle Base RAM-VB-105

Notes

Low profile design keeps mount away from passenger leg space. This base will not interfere with factory installed console or 4WD lever.

RAM Mounting Systems

8410 Dallas Ave S Seattle, WA 98108 Phone: (206) 763-8361 Fax: (206) 763-9615 www.rammount.com support@rammount.com



RMR-INS-VB-105

Item Number RAM-VB-105 & RAM-VB-105-SW1

RAM No-Drill TM Seat Bases RAM Mounting Systems

INSTALLATION INSTRUCTIONS

- 1. Move the passenger seat back to its rearmost position and remove the front seat rail bolts on the passenger side.
- 2. Without moving the seat, place the No-Drill™ base over the front of the seat frame legs.
- 3. Align the holes in the base with those of the seat frame legs. The pedestal platform should be near the console.
- 4. Re-install the seat bolts and fully tighten.

RAM Mounting Systems

8410 Dallas Ave S Seattle, WA 98108 Phone: (206) 763-8361 Fax: (206) 763-9615 www.rammount.com support@rammount.com



RMR-INS-VB-105