

**Item Number** \_\_\_\_\_

RAM-VB-135MH1 & RAM-VB-135MH1-SW1

# RAM No-Drill™ Seat Bases

RAM Mounting Systems

## SPECIFICATIONS

**Placement**

Passenger side on the floor, under front seat

**Drilling Required**

No - uses existing seat bolts

**Seat Configuration**

Bucket

**Construction/Finish**

Steel/Black Powdercoat

**Pole or Pedestal**

Sold Separately

**Weight**

5 lbs.

**Dimensions**

A = 18.5", B = 7.5", C = 1.875"

Hole Center = 15.875"

**Features**

Installs in minutes with no drilling required  
Low profile keeps mount away from passenger leg space

**Notes**

The RAM-VB-135MH1 will not fit Honda Element vehicles with under seat speakers.

**RAM Mounting Systems**

8410 Dallas Ave S  
Seattle, WA 98108  
Phone: (206) 763-8361  
Fax: (206) 763-9615  
www.rammount.com  
support@rammount.com



RAM-VB-135MH1-SW1



RAM-VB-135MH1



RMR-INS-VB-135MH1

**Item Number** \_\_\_\_\_

RAM-VB-135MH1 & RAM-VB-135MH1-SW1

# RAM No-Drill™ Seat Bases

RAM Mounting Systems

## INSTALLATION INSTRUCTIONS

1. Move the passenger seat back to its rearmost position and remove the front seat rail bolts. Store these bolts.
2. Place the supplied stand offs over the holes in the seat frame legs and rest the No-Drill™ base on top of these.
3. Align the holes in the base, stand offs, and seat frame legs with those in the floor board. The pedestal platform should be near the console.
4. Pass the supplied longer bolts with washers through to the holes in the floor board and start the thread by hand.
5. Using a socket wrench, fully tighten the bolts to secure the no drill base into the vehicle.
6. After a week of use, check seat bolts and re-tighten if necessary.

**RAM Mounting Systems**  
8410 Dallas Ave S  
Seattle, WA 98108  
Phone: (206) 763-8361  
Fax: (206) 763-9615  
[www.rammount.com](http://www.rammount.com)  
[support@rammount.com](mailto:support@rammount.com)



RMR-INS-VB-135MH1