SPECIFICATIONS

Placement

Passenger side on the floor, under front seat

Drilling Required Pole or Pedestal
No - uses existing seat bolts Sold Separately

Seat Configuration Weight 4.8 lbs. Bucket

Construction/Finish Steel/Black Powdercoat

Dimensions

Length = 18.125", Depth = 9.625" Height = 2.25", Hole Centers = 16.625"

<u>Features</u>

Installs in minutes with no drilling required Low profile keeps mount away from passenger leg space

Misc.

Rock solid construction

Lifetime warranty



Shown In Use

RAM Mounting Systems

8410 Dallas Ave S Seattle, WA 98108 Phone: (206) 763-8361 Fax: (206) 763-9615 www.rammount.com support@rammount.com



RMR-INS-VB-150

INSTALLATION INSTRUCTIONS

- 1. Move the passenger seat back to its rearmost position and remove the front seat rail bolts. Store these bolts.
- 2. Without moving the seat, place the No-Drill TM base over the front of the seat frame legs.
- 3. Align the holes in the base with those of the seat frame legs. The pedestal platform should be near the console.
- 4. Using the supplied longer seat bolts and washers, secure the no drill base over the seat frame legs.
- 5. Fully tighten the seat leg bolts. It is suggested to start these bolts by hand to avoid cross threading.

RAM Mounting Systems

8410 Dallas Ave S Seattle, WA 98108 Phone: (206) 763-8361 Fax: (206) 763-9615 www.rammount.com support@rammount.com



RMR-INS-VB-150