

**Item Number**  
RAM-VCA-115

# RAM Console Leg Kits

RAM Mounting Systems

## Console Leg Kit for the CHEVROLET IMPALA POLICE PACKAGE (2012-2015)

### SPECIFICATIONS

**Drilling Requirements:**

None. Kit utilizes existing vehicle hardware and anchor points.

**Finish:**

Black Powder Coating

**Placement:**

Over transmission hump



### INSTALLATION INSTRUCTIONS

The purpose of this instruction sheet is to illustrate the manufacturer's recommended method of installation for the RAM-VCA-LEG-115 that includes front legs and short top plate with a bagged hardware kit. Installation should be done prior to the install of a prisoner partition if possible.

1. To begin, the front seats must be removed from the vehicle floor. Slide the seats all the way forward to access and remove the two seat bolts found at the rear of the seat frames. This requires a 15MM socket.
2. After removing the seat bolts, slide the seat all the way to its most rear-ward position. On the side of the seat is a lever to recline the seat. Recline the back rest of the seat to at least a 45 degree angle. Next, lift the seat upward and pull back so that the front seat leg hooks release from the slots in the floor board. Be very careful so as not to damage any electrical connections under the seat.
3. Next, position the brackets with the rectangular cut out over the slots in the floor board. Be sure to position with the side flange away from the hump. See picture below. make sure there is clearance around the seat leg hooks. Once installed, the base should not be pinched in between the seat legs and floor board. You should be able to move the base slightly even after the seat leg hooks are re-inserted into the floor slots. If this is not possible, you will need to re-align the legs and try again. Once the legs have been properly aligned and the seat leg hooks are back in their slots, re-install the bolts at the back of the seat and fully tighten.
4. Now that the rear seat bolts are fully tightened, push the leg assembly back so that it is as close as possible to the seat frame legs.
5. Using the two T-shaped legs included in the kit, insert each into the space between the seat leg hooks. It will be necessary to insert the tabs at an angle as there is little clearance for these plates. Once inserted, press the plate down so the slots drop over the two studs. Secure the plates with the 1/4-20 hardware provided and a 1/2" wrench.

**Disclaimer regarding mounting of product:**

National Products Inc. and/or RAM Mounting Systems is not liable under any theory of contract or tort law for any loss, damage, personal injury, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicles or any other application. In order to safely install and use RAM Mounting System or National Products Inc. products full consideration of vehicle occupants, vehicle systems (i.e. the location of fuel lines, brakes lines, electrical, drive train or other systems), air-bags and other safety equipment is required. RAM Mounting Systems and National Products Inc. specifically disclaims any responsibility for the improper use or installation of its products not consistent with the original vehicle manufacturers specifications and recommendations.

**RAM Mounting Systems**  
8410 Dallas Ave S  
Seattle, WA 98108  
Phone: (206) 763-8361  
Fax: (206) 763-9615  
www.rammount.com  
support@rammount.com



RMR-INS-VCA-LEG-115

**Important product notes for:  
Console applications**

**RAM Console Leg Kits**  
RAM Mounting Systems

**Area must be open or be made open to fit leg kits**

**SPECIFICATIONS**

**Drilling Requirements:**

No drilling required for this kit. This is a vehicle specific kit.

**Finish:**

Black Powder Coating

**Placement:**

Over transmission hump



**INSTALLATION REQUIREMENTS**

The area between the front seats must be accessible in order to mount the leg kits and top plates to support a console.

The area must be open between bucket seats or, if the vehicle has a 40/20/40 front bench seat or similar configuration, the center section must be removed.

The installed RAM-VC-LEG kit should be installed in a manner that does not interfere with the operation of shifters, levers.

For some vehicles, there may be room between the center of the bench seat front and the dash of the vehicle. If removing the center section of the bench seat is not an option, but there is room at this location, consider the universal leg kit, short top plate, and short console box as a possible solution.

**If the vehicle is equipped with a factory installed center console, make sure it can be removed without:**

1. Permanently disabling the vehicle.
2. Exposing sensitive electrical equipment to harm.
3. Exposing mechanical systems to harm.
4. Interfering with factory installed safety equipment.

Some factory installed equipment and consoles cannot be removed. If this is the case for your vehicle, consider other RAM products designed for mounting electronics safely and securely in your vehicle.



**RAM Mounting Systems**  
8410 Dallas Ave S  
Seattle, WA 98108  
Phone: (206) 763-8361  
Fax: (206) 763-9615  
www.rammount.com  
support@rammount.com



RMR-INS-VCA-LEG-115