

Item Number _____

RAM-VB-172 & RAM-VB-172-SW1

RAM No-Drill™ Seat Bases

RAM Mounting Systems

SPECIFICATIONS

Placement

Passenger side, in front, where seat frame meets floor board.

Drilling Required

None - uses existing seat bolts

Seat Configuration

Bucket

Pole or Pedestal

Ordered Separately

Weight

6.1 lbs

Construction/Finish

Steel/Black Powdercoat

Dimensions


A = 18.23", B = 7", C = 1.95",
Hole Center = 16.31"

Features

Installs in minutes with no drilling required.
Lifetime warranty!



Complete Vehicle Mount
RAM-VB-172-SW1



Vehicle Base
RAM-VB-172

RAM Mounting Systems

8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



RMR-INS-VB-172

Item Number _____

RAM-VB-172 & RAM-VB-172-SW1

RAM No-Drill™ Seat Bases

RAM Mounting Systems


INSTALLATION INSTRUCTIONS

Depending on your make and model, there may be pieces of plastic trim that cover the lower front of the seat frame legs. This will need to be removed and stored. If you wish to reinstall this piece of trim, you will have to modify it to fit over the stamped metal base.

1. Move the passenger side seat to its rearmost position. Using socket wrench, loosen and remove the two bolts holding the seat frame legs to the floor board.
2. Place the No-Drill™ base over the seat frame legs with the pedestal platform near the center of the vehicle. Note that for the Ford Fusion, the base will install under the seat frame legs, not over them.
3. Re-install the two seat frame bolts. Start the thread by hand and then fully tighten with the 18MM wrench.

NOTE: For the Fiesta, the base will install over the top of the seat frame legs, not under them.

The photo below depicts the install into a Ford Fusion. The arrows show areas where the fit is tight. This base does touch the carpeting of the center hump. It will also touch and flex slightly the plastic seat leg covers. This does not affect the functionality or appearance of the seat leg covers.



RAM Mounting Systems

8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



RMR-INS-VB-172