


## Parts Index



\* not to scale

Patented & Pats. Pend.  
rammount.com/ip




### 1 Docking Cup Assembly

Connect (A) Docking Cup to (B) Dock Body using 3 (D) Screws. Then connect (C) Dock Ramp to (B) Dock Body using remaining 2 (D) Screws.




### 2 Top Latch Assembly

Connect (G) Latch Housing to top of (B) Dock Body using (I) Screws and (J) Nuts. Connect (H) Housing Cover to (G) Latch Housing using (K) Screw.



### 3 Mount Assembly

Connect GDS® Tough-Dock™ to mounting components (not included) using (E) Screws and (F) Nuts.



RPR-INS-GDS-DOCKB-1



#### Safety Precaution

Do not install this product near or over an airbag deployment area or in a location that obstructs the driver's vision or interferes with vehicle operation. National Products, Inc does not assume responsibility or liability for any such personal injury, death or property damage.