



1 Docking Cup Assembly


Connect (A) Docking Cup to (B) Dock Body using 5 (D) Screws. Then Connect (C) Dock Ramp to (B) Dock Body using remaining 4 (D) Screws.






2 Top Latch Assembly

Connect (G) Latch Housing to top of (B) Dock Body using (I) Screws and (J) Nuts. Connect (H) Housing Cover to (G) Latch Housing using (K) Screw.



6 Mount Assembly

Connect GDS[®] Tough-Dock[™] to mounting components (not included) using **(E) Screws** and **(F) Nuts**.



RPR-INS-GDS-DOCKB-2

Safety Precaution

Do not install this product near or over an airbag deployment area or in a location that obstructs the driver's vision or interferes with vehicle operation. National Products, Inc does not assume responsibility or liability for any such personal injury, death or property damage.

.....