

Item Number
RAM-VB-156

RAM No-Drill™ Seat Bases

RAM Mounting Systems

SPECIFICATIONS

Placement

Passenger side near floor using seat frame as anchor.

Drilling Required

No - uses existing vehicle hardware

Seat Configuration

Bucket

Construction/Finish

Steel/Black Powdercoat

Pole or Pedestal

Purchased Separately

Weight

4.5 lbs.

Dimensions

A = 19.875", B = 7.25", C = 2.125"

Hole Center = 17" and 18.25"

Features

Installs in minutes with no drilling required
Won't interfere with passenger leg space

Misc.


Rock solid construction
Lifetime warranty

RAM Mounting Systems

8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



Shown In Use



RAM-VB-156



RMR-INS-VB-156

Item Number
RAM-VB-156

RAM No-Drill™ Seat Bases

RAM Mounting Systems

INSTALLATION INSTRUCTIONS

Note: Depending on the vehicle trim level, there may be plastic covers over the seat frame legs. This will need to be removed in order to install the base. Once installed, these can sometimes be replaced. Otherwise, store them for use later should the base be removed.

1. Move the passenger seat back to its rearmost position and loosen the front seat rail bolts or nuts. It may be necessary to loosen the two nuts or bolts at the rear of the seat as well for some vehicles in order to raise the front of the seat enough to clear the no drill base.
2. Gently lift the front of the seat to create a small gap between the seat frame and seat track.
3. Align the slots in the base with the seat bolts and slide the base into place. Press the no drill base as far in as possible so that the back of the slots engage the seat bolts. The pedestal platform should be near the console.
4. Re-tighten the bolts or nuts to secure the no drill base in place.



RAM Mounting Systems
8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



RMR-INS-VB-156