

Item Number _____

RAM-VB-175 & RAM-VB-175-SW1

RAM No-Drill™ Seat Bases

RAM Mounting Systems

SPECIFICATIONS

Placement

Passenger side between seat track & seat frame.

Drilling Required

No - uses existing seat bolts

Seat Configuration

Bucket

Construction/Finish

Steel/Black Powdercoat

Pole or Pedestal

Purchased Separately

Weight

4.5 lbs.

Dimensions

A = 19.875", B = 7.25", C = 2.125"

Hole Center = 17" and 18.25"

Features

Installs with no drilling required
Minimal intrusion into passenger leg space

Misc.


Durable construction
Lifetime warranty

RAM Mounting Systems

8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



RAM-VB-175-SW1



RAM-VB-175



RMR-INS-VB-175

Item Number _____

RAM-VB-175 & RAM-VB-175-SW1

RAM No-Drill™ Seat Bases

RAM Mounting Systems

INSTALLATION INSTRUCTIONS

1. Move the passenger seat back to its rearmost position and loosen the front seat rail nuts with a 15MM wrench.
2. Gently lift the front of the seat to create a small gap between the seat frame and seat track.
3. Align the slots in the base with the seat bolts and slide the base into place. Press the No-Drill™ base as far in as possible so that the back of the slots engage the seat bolts. The pedestal platform should be near the console.
4. Re-tighten the nuts to secure the No-Drill™ base.

Special note: Once the base is installed, passenger side front seat travel will be limited. In order to collapse and store the mid row seat behind the front passenger seat, the front passenger seat must be moved all the way forward. With the base installed, this will not be possible. The mid row seat should be left up or stowed, whichever it to be the most common orientation, prior to the installation of this product.



RAM Mounting Systems
8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



RMR-INS-VB-175